




Pegasus

# PP-360/N

## Access Controller


Operational Manual

Ver.14.1



## Packing List

1



### DESCRIPTION

### Q'TY

The system unit	1 unit
① 9 Pin connector (Blue)	1 pcs
② 8 Pin connector (White)	1 pcs
③ 3 Pin connector (White)	1 pcs
④ Screw	2 pcs
⑤ Free wheeling diode	1 pcs

## Features

2

1. Read 125 KHz proximity card with EM chip internally for standard model.
2. The system parameters are stored in non-volatile memory for 10 years data retention as power off without any external power supply.
3. **1000** card holders with 8 digits I.D. number by learning reads.
4. The door released time, door monitoring time could be freely programmed for 1 or 8 seconds.
5. With exit push button for exit or remote exit control.
6. Low power CMOS CPU with watch-dog function to assure best performance.
7. ABS case for easy indoor installation.


## Specification

3

Dimensions	: 118(L) x 75(W) x 17(H)mm
Net weight	: 98g $\pm$ 5%
Power supply	: DC 12V $\pm$ 10% 40mA(Standby) / 70mA(Work)
Operating temperature	: 0°C ~ 70°C
Operating humidity	: 10%~90%
Card standard	: EM 125KHz
Waterproof	: Yes

## Panel description / Bottom view

4



**JP3** — Short to system initialization

**DIP1** — For defining master card


**J1** — 8 pins connector for alarm output

**J2** — 9 pins connector for access port

**J4** — 3 pins connector for tamper switch output

## Wiring connectors and PIN assignment

5



### A. J2-9P Blue (For power input and access functions)


1 (Red)	Power "+"	+12V DC input
2 (Black)	Power "-"	GND
3 (Brown)	COM.	Relay A (COM.)
4 (Orange)	N.O.	Relay A (N.O.)
5 (Yellow)	N.C.	Relay A (N.C.)
6 (Green)	Exit push button	
7 (Blue)	Door Monitor	
8 (Purple)	Security sensor	
9 (Gray)	X	



### B. J1-8P White (For alarm output)

A (Brown)	---
B (Red)	---
C (Orange)	---
D (Yellow)	---
E (Green)	Alam output in dry contact (COM.)
F (Blue)	Alam output in dry contact (N.O.)
G (Purple)	---
H (Gray)	---





### C. J4-3P White (For tamper switch output)


- 1 (Yellow) → (COM.)
- 2 (Green) → (N.C.)
- 3 (Blue) → (N.O.)

#### Wiring example

6


#### 1. Wiring connection with external relay and power supply (such as electric strike lock)

J2-9 blue pin(For access control)



#### 2. Wiring connection with external relay and power supply for heavy load locks (such as magnetic lock or drop bolt type lock)

J2-9 blue pin(For access control)



#### Instruction for card reading

7

#### 1. How to define Master card ?

- 1.A. Dial the **DIP1** switch to **ON**.
- 1.B. Approach one of proximity card to the reader as Master card.
- 1.C. The buzzer beeps and status LED in **green** color.
- 1.D. **Turn off** the **DIP1** switch to normal operation state. (Buzzer stop then status LED in **orange** color)

#### 2. How to add user card?

- 2.A. Approach the Master card to the reader.
- 2.B. The buzzer beeps and the status LED flashes in **red/green** color. (**Each user card flash once**)
- 2.C. Approach the proximity cards which you want to add it to the reader one by one.

- 2.D. After adding the cards completely, please approach the Master card to the reader again.

#### 3. How to delete user card?

- 3.A. Approach the Master card to the reader **twice**.
- 3.B. The buzzer beeps **twice** and the status LED flashes in **red/green** color.
- 3.C. Approach the proximity cards which you want to delete it to the reader one by one.
- 3.D. After deleting the cards completely, please approach the Master card to the reader again.
- 3.E. The reader beeps error sounds(3 beeps) to end the procedure.


#### 4. How to set door released time?

(Default value by initialization is 5 sec.)

**Default status is door monitoring status.**

Please connect the J2-9 blue pin connector **blue** wires with **black** wires (GND) as blow. It means close the door monitoring function and can set door release time.

J2-9 blue pin



- 4.A. Master card approach to the reader **three times**, then the door release time are changed to **10 sec**.
- 4.B. Master card approach to the reader **three times again**, then the door release status are **normal open(green LED) /normal close (red LED)**.
- 4.C. Master card approach to the reader **three times again**, then the door release time are changed to **1 sec**.
- 4.D. Master card approach to the reader **three times again**, then the door release time are back to **5 sec**. (initial default value)
- 4.E. Use method of door release time is the cycle (approach to the reader three times once) - 5 sec. to 10 sec. to NO/NC to 1 sec. to 5 sec.

#### 5. How to delete all of user cards?

- 5.A. Approach the Master card to the reader **four** times.
- 5.B. The buzzer beeps and the status LED flashes in **red/green** color.
- 5.C. All of user cards and Master card will be deleted, and the status LED will form **green** to **red** color. After **red** LED status, deleted card status is done. (**Not more than 2 sec. between triple and fourth time.**)

※ In this controller, master card can not be deleted and just only create one master card.